


CorpsMap HOW-TO



The menu bar along the top of the screen contains the navigation and query tools. Only one tool is active at a time and is indicated by the indentation. In the above screenshot the “zoom in” tool is active.

Hovering over a tool will display a tool tip describing the tool’s function:



Navigation:



The tools on the left side of the toolbar are used to move around the map.

Zoom to maximum extent (1.1): Changes the view to the project’s default zoom level

Zoom in/out (1.2): Click once to zoom or click and drag to zoom to a particular area. The mouse wheel can also be used to change the zoom level.

Pan (1.3): Click and drag to move the map

Displaying Well Test Results (Query):




The query tools in the middle of the toolbar are used to display well results. Select the popup tool (2.2) then click on a point on the map to bring up results.

Clear highlighted features (2.1): De-selects everything on the map

Popup info query (2.2): Click a feature to display the details. This is one of the most commonly used tools.

Table info query (2.3): Displays an exportable table at the bottom of the screen

Map:



BaseMap: Change the underlying map to a different format. Certain basemaps do not allow for close-in zooming, choose the Google Hybrid or Google Satellite basemap for maximum zooming ability.

For questions about and test results and content contact Dan Sacks (206-316-3962, dan.i.sacks@usace.army.mil)

For technical questions contact Lawrence Lin (206-764-7162, lawrence.p.lin@usace.army.mil)